

Instruction for Use

021011/02/01

Wind Alarm Instrument 3 4.3242.0x.00x



ADOLF THIES GmbH & Co. KG

Hauptstraße 76 Box 3536 + 3541 Phone ++551 79001-0 www.thiesclima.com 37083 Göttingen Germany 37025 Göttingen Fax ++551 79001-65 info@thiesclima.com

Contens

1	Models	2		
2	Range of Application3			
3	Mode of Operation	3		
4	Recommendation Site Selection	3		
	Mounting45.1Mechanical Mounting45.2Electrical Mounting4			
6	Circuit Diagram	1		
7	Operation 7 V.1 View V.2 Setting the Wind Alarm Threshold: X.3 Switch On Delay:	7 3		
	7.3 Switch-On Delay: 8 7.4 Switch-Off Delay: 9			
8	3 Maintenance			
9	Technical Data10)		
10	0 Dimensional Drawings			
11	1 EC-Declaration of Conformity			

1 Models

Order Number	Construction	Supply Voltage
4.3242.01.000	Panel mounting	230 V / 50 Hz
4.3242.01.001	Panel mounting, with additionally integrated acoustic signal transmitter	230 V / 50 Hz
4.3242.05.000	Panel mounting	15 V DC
4.3242.06.000	Panel mounting	18 25 V DC
4.3242.08.000	Panel mounting	115 V / 50 Hz
4.3242.14.000	Euro- Card	230 V / 50 Hz
4.3242.15.000	Euro- Card	15 V DC
4.3242.16.000	Euro- Card	18 25 V DC

2 Range of Application

Wind Alarm Instrument 3 is used in conjunction with a wind transmitter (4.3303.22.000) to initiate preventive measures to protect wind-endangered objects such as, for example, cranes, bridges, masts, greenhouses, window blinds and awnings.


3 Mode of Operation

The wind transmitter (4.3303.22.000) delivers impulses proportionally to the wind velocity. These pulses are acquired and processed by the wind alarm instrument 3.

The wind alarm is released by a relay. If the wind velocity exceeds a preset value the relay switches after a certain delay and releases the alarm. If the wind velocity falls below the preset value, the relay deactivates after a certain delay.

The switch-on- and switch-off-delay prevents the relay from permanently switching-over in case of short-term exceeding or falling below the threshold. The delay periods are selectable by means of a rotary switch.

Example of a Wind Alarm System:



4 Recommendation Site Selection

The wind alarm instrument 3 is designed for indoors mounting. In case of outdoor application an additional over-housing with the respective protection is necessary.

Remark

Please pay attention to the temperature application range when selecting a site.

5 Mounting

Caution

The device should only be installed and connected by qualified technicians. The general engineering regulations and provisions and standards applicable must be observed.

5.1 Mechanical Mounting

Construction: Panel mounting

The Wind Alarm Instrument 3 is designed to be mounted to walls in roofed-over rooms. To do this, first unscrew the transparent cover, revealing the four screw borings. Now mount the instrument to the wall by inserting 4 mm screws into these four borings.

Construction: Euro- Card

The complete pc-board is put into the guide track of a suited card hopper so that the male multipoint connector catches the female multipoint connector of the card hopper.

5.2 Electrical Mounting

Connect the instrument electrically in accordance with the following circuit diagrams as appropriate for the wind transmitter being used. This must be carried out by an electrician or some other expert.

Remove the white front plate. Lead the connecting lines through the respective screw-type conduit fitting and connect as shown in the combination circuit diagram (see Chapter 6).


The following recommendation applies for the operation of a wind transmitter with heating:


0,75 mm² cable lead cross section, max. 50 m length of lead

6 Circuit Diagram

Attention:

Circuit diagrams below shows the relay in "alarm off" position. The condition is valid when operating voltage is supplied to the wind warn unit and alarm set point is not reached.






7 Operation

The positions (0...9) of the rotary switches for the settings are marked with the model "wall housing". With model "Euro-card" the arrangement is identical with model "wall housing".

A 3-digit LED display indicates the instantaneous value of the wind velocity.

An LED signalises the alarm status: red = threshold exceeded / wind alarm on.

7.1 View



7.2 Setting the Wind Alarm Threshold:

The threshold is set in double figures directly; hereby, the figures appearing in the field display the value.

The switching point of the wind alarm threshold is selectable in the range from 0...50 m/s by means of the **rotary switches 1 and 2**.

Rotary switches 1	Rotary switches 2	Alarm threshold
range of 10	range of 1	
Position	Position	Depending on position
0	0	
1	1	
2	2	
3	3	
	4	1 –50 m/s
	5	1 –50 m/s
	6	
	7	
	8	
	9	

Setting example: R1 = 2 and R2 = 1 = Alarm threshold 21 m/s

7.3 Switch-On Delay:

By means of **rotary switch 3** the switch-on delay of the wind alarm is set for the case of a permanent exceeding of the wind alarm threshold .

The switch-on delay is set in single figure from 0...18 seconds in switch positions of 10. Please consider that the figure appearing in the window is to be multiplied by "2".

Rotary switch 3	Switch-on delay
Position	[Seconds]
0	0
1	2
2	4
3	6
4	8
5	10
6	12
7	14
8	16
9	18

Setting example: R3 = 3 = Switch-on delay 6 sec

7.4 Switch-Off Delay:

By means of **rotary switch 4** the switch-off delay of the wind alarm is set for the case of a permanent falling below the wind alarm threshold.

The switch-off delay is set in single figure from 0...18 minutes in switch positions of 10. Please consider that the figure appearing in the window is to be multiplied by "2".

Rotary switch 4	Switch-off delay
Position	[Minutes]
0	0
1	2
2	4
3	6
4	8
5	10
6	12
7	14
8	16
9	18

Setting example: R4 = **5** = Switch-off delay **10** min

After completion of all mounting- and setting works the wind alarm instrument 3 is to be closed again by installing the front plate and clear cover.

8 Maintenance

With proper mounting the instrument operates maintenance-free.

Remark:


Please pay attention to maintenance advices of the wind transmitter

9 Technical Data

Order- No.	4.3242.01.000 4.3242.05.000 4.3242.06.000 4.3242.08.000	4.3242.14.000 4.3242.15.000 4.3242.16.000
Wind alarm range	050 m/s	050 m/s
Resolution	1 m/s	1 m/s
Measuring value input	Pulses (0- 1042Hz = 0- 50 m/s)	Pulses (0- 1042Hz = 0- 50 m/s)
Switch-on delay	118 sec.	118 sec.
Switch-off delay	118 min.	118 min.
Relay output	throw-over switch, one-pole, potential-free	throw-over switch, one-pole, potential-free
Contact rating	200 W, 24 V DC,	200 W, 24 V DC
	100 W, 250 V DC	100 W, 250 V DC
	1000 VA, max. 8 A	1000 VA, max. 8 A
Operating voltage	See model	See model
Ambient temperature	040° C	040°C
Construction	Panel mounting	Euro- Card
Connection	Screwed cable gland, connecting strip, 16 pole	Terminal strip, 32-pole
Dimensions	120 x 200 x 75 mm	approx. 100 x 170 x 50 mm
Type of protection	IP 65 acc. DIN 40050	Mounted in card hopper
Weight	0.85 kg	0.3 kg

10 Dimensional Drawings

Construction: Panel mounting



Manufacturer:	ADOLF	THIES	GmbH	&	C o.	KG
	Hauptstr. 76					
	D-37083 Götting	jen				
	Tel.: (0551) 7900	01-0				
	Fax: (0551) 790	01-65				
	email: Info@Thi	esClima.com				

Description of Product: Wind Alarm Instrument

Document-No.: 001290

Article No.	4.3241.00.000	4.3241.00.001	4.3241.02.000	4.3241.02.001
	4.3241.02.900	4.3241.03.000	4.3242.01.000	4.3242.02.000
	4.3242.05.000	4.3242.06.000	4.3242.14.000	

Month: 06 Year: 08

specified technical data in the document: 020713/04/08; 020534/02/99

The indicated products correspond to the essential requirement of the following European Directives and Regulations:

2004/108/EC	DIRECTIVE 2004/108/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL
	of 15 December 2004 on the approximation of the laws of the Member States relating to
	electromagnetic compatibility and repealing Directive 89/336/EEC

2006/95/EC DIRECTIVE 2006/95/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 12 December 2006 on the harmonisation of the laws of Member States relating to electrical equipment designed for use within certain voltage limits

552/2004/EC Regulation (EC) No 552/2004 of the European Parliament and the Council of 10 March 2004 on the interoperability of the European Air Traffic Management network (the interoperability Regulation)

The indicated products comply with the regulations of the directives. This is proved by the compliance with the following standards:

Reference number	Specification
IEC 61000-6-2: 2005	Electromagnetic compatibility Immunity for industrial environment
IEC 61000-6-3: 2006	Electromagnetic compatibility Emission standard for residential, commercial and light industrial environments
IEC 61010-1: 2001	Safety requirements for electrical equipment for measurement, control and laboratory use. Part 1: General requirements

Place: Göttingen

Legally binding signature?

Wolfgang Behrens, General Manager

Date: 27.06.2008

issuer:

Joachim Beinhorn, Development Manager

This declaration certificates the compliance with the mentioned directives, however does not include any warranty of characteristics. Please pay attention to the security advises of the provided instructions for use.

ADOLF THIES GmbH & Co. KG

Hauptstraße 7637083 Göttingen GermanyP.O. Box 3536 + 354137025 GöttingenPhone ++551 79001-0Fax ++551 79001-65www.thiesclima.cominfo@thiesclima.com



- Alterations reserved -

